




Wireless IR Transmitter for airconditioning control - CCA009

Wireless IR transmitter works like a mimic of your original remote control for an air conditioner.

It needs to be installed with its IR LED towards of air conditioner's IR receiver.

By connecting 12V power cable the pairing mode will be activated - IR LED on its front side will start flashing with orange color.

Alternatively it is possible to stick it onto the frame of an air conditioner panel and connect the power wiring into an air conditioner device.



The correct option must be set also in the Wireless device settings of the mobile App. Please check your air conditioner model carefully to avoid possible function limitations.